

cleaning instructions.



Clean your machine, after every use. A well-maintained machine is the one, that runs for years.



Dry your cloth before cleaning, as exposing the machine directly to water might make it malfunction. Remember, the machine has minute electronic components.



After every use, remove the feeding pipe, along with the food plate holder. Rinse them in water, wipe with dry cloth. This prevents food particles from staying back and contaminating the next fresh batch.



Keep the machine away from children. The machine has parts that might hurt them, when used without supervision.

StringsPRO

Strings**PRO**

String hoppers, simplified!

User Manual



A product from

Big Time Products

#24 | Mahalakshmi Temple Street
Masakalipalayam | Coimbatore
India | 641015 | +91 8220034449
support@bigtimeindia.com

dough preparation.



take

Have equal amounts of finely ground rice flour and boiling water using a kitchen scale or a vessel for accuracy.



mix

Place the rice flour in a mixing bowl and create a well in the center. Carefully pour the boiling water into the well, gradually incorporating it into the flour using a wooden spoon or spatula.



knead

Knead the ingredients thoroughly until a cohesive dough forms. You may need to adjust the amount of water slightly depending on the consistency of the dough.

machine operation.

manual mode

- Switch **ON** the machine.
- Fill the feeder pipe with kneaded flour.
- Place the feeder pipe in the machine.
- Push down the **Press button**, until the first string hopper is formed.
- Release the button, take the plate out.
- Place the new plate.
- Repeat the above process.

semi automatic mode

- Switch **ON** the machine.
- Press the **mode** button once, to change the mode to semi-automatic. (mode led slow blinking)
- Fill the feeder pipe with kneaded flour and place it in the machine.
- Push down the **Press button**, until you see some flour coming out.
- Release the button, discard the flour.
- Use the knobs Rotating speed & Pressing speed to set the desired settings.
- Place the food plate & push the Press button, once.
- Wait until the string hopper is formed, take the plate out and place the new plate in.
- Repeat the process.

machine operation.

contd.

fully automatic mode

- Switch **ON** the machine.
- Press the **mode** button once, to change the mode to fully-automatic. (mode led fast blinking)
- Fill the feeder pipe with kneaded flour and place it in the machine.
- Push down the **Press button**, until you see some flour coming out.
- Release the button, discard the flour.
- Use the knobs Rotating speed, Rotation count & Pressing speed to set the desired settings.
- Place the food plate.
- Wait until the string hopper is formed, take the plate out and place the new plate in.
- Repeat the process.

